



UniPoint System Configuration



UniPoint System Configuration

Product Code/ Item Description	1 Zone	2 Zones	3 Zones	4 Zones	5 Zones	6 Zones	7 Zones	8 Zones
657090 Zonemaster UniPoint Touchpad								
657093 Uni/MaxiPoint Damper Controller		2	3	4	5	6	7	8
657155 NEAT 24V Transformer Plug In								
657095 Control Cable 12M								
657094 Control Cable 3M			2	3	4	5	6	7
FULL KIT PRODUCT CODE	671912	671913	671914	671915	671916	671917	671918	671919

OPTION FOR BYPASS CONTROL SYSTEM

Product Code/ Item Description	1 Zone	2 Zones	3 Zones	4 Zones	5 Zones	6 Zones	7 Zones	8 Zones
657186 NEAT Supply Air Sensor with 7M lead								

Note: Motorised Dampers must be purchased separately

NOTE:

- 1: Zonemaster VAV, Unipoint RF and Unipoint/Maxipoint are all 24 volt powered and therefore do not require installation by an Electrician in most states. However check local regulations before fitting.
- 2: All Zonemaster products come with an easy to follow installation manual/user guide. We recommend that this is read and followed during installation for a fault free job.
- 3: For current pricing [contact](#) your nearest Polyaire branch or representative.